



FrameCo

LINE MAKER™

#14418

THE RAPID LINE MAKER



fig.1.





fig.2.



fig.3.



The Line Maker™ is a quick and easy way to mark a mat ready for bevel cutting.

Simply set the arm to the desired border width and then mark out all sides. An alternative head is available to take gold and silver pens used for mat decoration.

See item #14419 - Pen Head Holder.

How to use the Line Maker™

1. Twist the pencil into the holder for a firm fit - takes most brands of pencils. Tighten the locking screw.
2. We recommend you use a 2H pencil for fine lines.
3. To set the width, first make a mark on the back of the board to the desired border width using a standard ruler. Loosen the star handle and place the base of the Line Maker™ up against the mat edge. Adjust the arm so that the pen head touches the dot. Tighten the star handle - see fig 3.
4. Position the Line Maker™ base up against the outer edge of the mat, then move the tool back and forth, making a clean straight line on the back of the mat from one edge to the other. Repeat this procedure for all 4 sides. These are your cutting lines and indicate the start and stop positions- see fig 2.
5. Keep the pencil sharp for clean light lines.
6. The tool can be adapted with an alternative head so you can draw decorative "line work" on the face of the mat. This can be done with a pencil, coloured pens or gold and silver pens.

#14418 Line Maker™