




FrameCo FRAME STOP

#15620

FRAME SUPPORT SYSTEM



More power and better control to insert flexipoints and nails.



PushMaster inserts flexipoints and backing nails. Use the groove or slots in the head of the PushMaster for this purpose. The side of the frame needs to be firmly supported when inserting backing points. If the flexipoints bend or the timber is very hard, tap the PushMaster with a mallet.

#15620 FrameCo Frame Stop